



**Q. Can I access the Caller ID without entering a Password each time?**

**A. Yes, although the DX80 and DX120 systems' are defaulted to require manual entry of the password 0000 or 9999 to display the Caller ID list, you can program individual phones to be able to automatically enter the required password when you press the Caller ID DSS button on your phone.**

Programming for Caller ID (CID) to display (show) without manually inputting in the Passwords (0000 - at station 110 - or the 9999 at other stations) each time:

With the handset on hook

Press **FEATURE # 3**

The LCD will ask for the DSS button you want to program

Press The **CALLER ID** button that's on your phone already - the LCD will show what's programmed there already.

And will display **SHOW** or **CHG**

Press **CHG**

It will display **DIR** or **FTR** - PRESS **FTR**

Press **FEATURE 6 # 9 9 9 9** save (see note below)

You can then pick up the handset and hang up.

Press the CALLER ID DSS button and you should be able to press Show now. You need to do this on each phone.

Note if you are programming **STATION 110** press **0 0 0 0** instead of **9 9 9 9**.