

# SYSTEM VOICE MAIL MANAGEMENT – ADD DELETE BOXES, CHANGE GREETINGS AND TIME


Default standard Procedures: Press ITCM

Press 6 0

Press # (Pound)

“Enter Mail Box “ Enter Supervisors Mail Box Number

“Enter Password” Enter Default Password. Follow Prompts as illustrated in this tree



\* **CAUTION** – Select and modify these options **ONLY** under the guidance of your system technician. Using these options incorrectly may keep the system from effectively processing calls and performing messaging functions. This guide does not include information on working with these functions.