



FAQ: How do I change the name display on my **SBX IP 320** 24 or 8 button phone:

A name can be displayed on your LCD instead of your station number.

1. Press the **TRANS / PGM** button.
2. Dial “**7 4**”.
3. Enter your name (see Entering character table below).
4. Press the **[HOLD / SAVE]** button.

Entering Characters:

. - 13	A - 21	D - 31
Q - 11	B - 22	E - 32
Z - 12	C - 23	F - 33
1 - 10	2 - 20	3 - 30
G - 41	J - 51	M - 61
H - 42	K - 52	N - 62
I - 43	L - 53	O - 63
4 - 40	5 - 50	6 - 60
P - 71	T - 81	W - 91
Q - 72	U - 82	X - 92
R - 73	V - 83	Y - 93
S - 74	8 - 80	Z - 94
7 - 70		9 - 90
Blank - *1	0 - 00	
: - *2		
. - *3		